



1. Holding over BWA shall be accomplished according to the approach to be made
2. PARSI H.P. is LATERALLY separated with TINAU H.P. and BWA H.P. (left hand Pattern)
3. Transition from TINAU H.P. to PARSI H.P.
Climb to 5000ft or above on TINAU H.P. then commence 10DME ARC to intercept R080 to PARSI H.P.
4. Transition from PARSI H.P. to TINAU H.P.
From PARSI, proceed on R080 inbound to BWA maintaining 5000ft or above. then intercept 10DME ARC to TINAU H.P.