

VNKT AD 2.18 ATS COMMUNICATION FACILITIES

Service Designation	Call Sign	Frequency	Hours of Operation **	Remarks
1	2	3	4	5
TWR	Kathmandu Tower	118.1 MHZ 118.5 MHZ	0015-1845	
SMC	Kathmandu Ground	121.9 MHZ	0015-1845	
APP	Kathmandu Approach	120.6 MHZ 125.1 MHZ	0015-1845	
ACC	Kathmandu Control	126.5 MHZ 124.7 MHZ	0015-1845	
ATIS	Kathmandu Terminal	127.0 MHZ	0015-1845	
A/G	Kathmandu Radio	6607 KHZ	0015-1245	For Domestic Flights

VNKT AD 2.19 RADIO NAVIGATION AND LANDING AID

Type of Aid MAG VAR Type of supported OP (for VOR/ILS/MLS give declinations)	ID	Frequency	OPR Hours	Position of Transmitting Antenna Coordinates	Elevation of DME Transmitting Antenna	Remarks
1	2	3	4	5	6	7
DVOR DME 0°W	KTM	113.2 MHZ CHN 79 X	H24	274025 N* 0852055E	1330 m	
NDB	KAM	318 KHZ	H24	274138 N* 0852113 E		
Locator Nalinchowk	LNC	252 KHZ	H24	273901 N* 0852754 E		
Locator Thecho	LTH	230 KHZ	H24	273645 N* 0851924 E		

Note: - Check current NOTAMS for latest information.

** 1) From Nov 16- Feb 15 (0045-1845) UTC 2) From Feb 16- Nov 15 (0015 -1845) UTC

* WGS -84 Coordinates