

|                 |  |              |
|-----------------|--|--------------|
| <b>ENR 1.4</b>  | <b>ATS Airspace Classification</b>   | ENR 1.4 - 1  |
| ENR 1.4.1       | Introduction   | ENR 1.4 - 1  |
| ENR 1.4.2       | Classification of airspaces  | ENR 1.4 - 1  |
| <b>ENR 1.5</b>  | <b>Holding, Approach and Departure Procedures</b>                          | ENR 1.5 - 1  |
| ENR 1.5.1       | General  | ENR 1.5 - 1  |
| ENR 1.5.2       | Holding Procedures   | ENR 1.5 - 1  |
| ENR 1.5.3       | Low Level Holding Areas (Tribhuvan International Airport)                  | ENR 1.5 - 2  |
| ENR 1.5.4       | High Level Holding Areas (Tribhuvan International Airport)                 | ENR 1.5 - 2  |
| ENR 1.5.5       | Holding Speeds   | ENR 1.5 - 2  |
| ENR 1.5.6       | Standard Instrument Departure (SID) and Standard Instrument Arrival (STAR) | ENR 1.5 - 2  |
| ENR 1.5.7       | Arriving flights   | ENR 1.5 - 2  |
| ENR 1.5.8       | Departing Flights  | ENR 1.5 - 5  |
| ENR 1.5.9       | Engine Starting Procedure  | ENR 1.5 - 5  |
| ENR 1.5.10      | Procedures for push back and engine start up at TIA                        | ENR 1.5 - 6  |
| ENR 1.5.11      | Information provided prior to Take off.                                    | ENR 1.5 - 6  |
| ENR 1.5.12      | Selection of Runway-in-Use for take off                                    | ENR 1.5 - 6  |
| ENR 1.5.13      | Selection of Turn  | ENR 1.5 - 7  |
| ENR 1.5.14      | Departure Instruction  | ENR 1.5 - 7  |
| ENR 1.5.15      | Take Off   | ENR 1.5 - 7  |
| ENR 1.5.16      | Separation Minima for Take Off   | ENR 1.5 - 7  |
| ENR 1.5.17      | Communication Failure Procedure  | ENR 1.5 - 8  |
| <b>ENR 1.6</b>  | <b>Radar Services and Procedures</b>                                       | ENR 1.6 - 1  |
| ENR 1.6.1       | Summary of services  | ENR 1.6 - 1  |
| ENR 1.6.2       | Secondary Surveillance Radar. (SSR)  | ENR 1.6 - 3  |
| ENR 1.6.3       | Radar and Communication Failure  | ENR 1.6 - 5  |
| <b>ENR 1.7</b>  | <b>Altimeter Setting Procedures</b>  | ENR 1.7 - 1  |
| ENR 1.7.1       | Introduction   | ENR 1.7 - 1  |
| ENR 1.7.2       | Basic Altimeter Setting Procedures   | ENR 1.7 - 1  |
| ENR 1.7.3       | Description of Altimeter setting region                                    | ENR 1.7 - 2  |
| ENR 1.7.4       | Procedures applicable to operators (including pilots)                      | ENR 1.7 - 2  |
| ENR 1.7.5       | The cruising levels to be observed when so required are as follows,        | ENR 1.7 - 3  |
| <b>ENR 1.8</b>  | <b>Regional Supplementary Procedures (DOC 7030)</b>                        | ENR 1.8 - 1  |
| <b>ENR 1.9</b>  | <b>Air Traffic Flow Management (ATFM)</b>                                  | ENR 1.9 - 1  |
| <b>ENR 1.10</b> | <b>Flight Planning</b>   | ENR 1.10 - 1 |
| ENR 1.10.1      | Procedures For The Submission Of A Flight Plan                             | ENR 1.10 - 1 |
| ENR 1.10.2      | Repetitive Flight Plan System  | ENR 1.10 - 2 |