

## VNVT AD 2.9 SURFACE MOVEMENT GUIDANCE AND CONTROL SYSTEM AND MARKINGS

1.	Use of aircraft stand ID signs, TWY guide lines and visual docking/parking guidance system of aircraft stands	Taxiing guidance signs at intersections with TWY and RWY and at holding positions. Guide lines at apron.
2.	RWY and TWY markings and LGT	RWY: 09/27, THR, TDZ, Center line, RWY edge marked and RWY END, THR, RWY edge have lights. TWY: Center line, holding positions at all TWY/RWY intersections marked and edge with blue lights.
3.	Stop bars	.....
4.	Remarks	-

## VNVT AD 2.10 AERODROME OBSTACLES

In area 2					
OBST ID/ Designation	Obstacle type	Obst. position	ELEV/HGT (mt)	Markings/Type color	Remarks
a	b	c	d	e	f
VNVT0B001	Tel TWR Antenna	26 27 42N 87 17 10E	140/68	Marked/LGTD	
V NVT0B002	VOR/DME Antenna	26 28 58N 87 14 58E	87/15	Marked/LGTD	

## VNVT AD 2.11 METEOROLOGICAL INFORMATION PROVIDED

1.	Associated MET Office	MET office, BIRATNAGAR AIRPORT
2.	Hours of service MET office outside hours	Available during Operation Hrs.
3.	Office responsible for TAF preparation periods of validity	NIL
4.	Type of landing forecast interval of issuance	NIL
5.	Briefing/Consultation provided	METAR
6.	Flight documentation language(s) used	Charts or Tabular forms Text English
7.	Charts and other information available for briefing or consultation	NIL
8.	Supplementary equipment available for providing information	Self- briefing terminal
9.	ATS units provided with information	Biratnagar TWR
10.	Additional information (limitation of service, etc.)	NIL